

# QT128C2X

128-Channel Short-Range  
Mechanical Lidar  
User Manual



# Contents

<b>About This Manual</b> .....	<b>1</b>	4.2	Settings .....	45
<b>Safety Notice</b> .....	<b>3</b>	4.3	Azimuth FOV .....	52
<b>1 Introduction</b> .....	<b>10</b>	4.4	Operation Statistics .....	55
1.1 Operating Principle .....	10	4.5	Upgrade .....	56
1.2 Lidar Structure .....	11	4.6	Log.....	57
1.3 Channel Distribution .....	12	4.7	Security .....	58
1.4 Specifications .....	14	4.8	Login.....	63
<b>2 Setup</b> .....	<b>16</b>	4.9	Cybersecurity Configuration.....	64
2.1 Mechanical Installation.....	16	<b>5 Communication Protocol</b> .....	<b>72</b>	
2.2 Interfaces .....	20	<b>6 Sensor Maintenance</b> .....	<b>73</b>	
2.3 Connection Box (Optional) .....	23	<b>7 Troubleshooting</b> .....	<b>75</b>	
2.4 Get Ready to Use .....	28	<b>Appendix I Channel Distribution</b> .....	<b>79</b>	
<b>3 Data Structure</b> .....	<b>29</b>	<b>Appendix II Absolute Time of Point Cloud Data</b> .....	<b>87</b>	
3.1 Point Cloud Data Packet .....	30	<b>Appendix III Power Supply Requirements</b> .....	<b>96</b>	
<b>4 Web Control</b> .....	<b>42</b>	<b>Appendix IV Legal Notice</b> .....	<b>98</b>	
4.1 Home .....	43			

# About This Manual

## ■ Using This Manual

- Make sure to read through this user manual before your first use and follow the instructions herein when you operate the product. Failure to comply with the instructions may result in product damage, property loss, personal injuries, and/or a breach of warranty.
- This user manual does not contain information on product certifications. Please check the certification marks on the product's bottom plate and read through the corresponding certification warnings.
- If you incorporate this lidar product into your product(s), you are required to provide this user manual (or the means to access this user manual) to the intended users of your product(s)
- This lidar product is intended as a component of an end product. It shall be evaluated in end product according to relevant standards.

## ■ Access to This Manual

To obtain the latest version:

- Visit the Download page of Hesai's official website: <https://www.hesaitech.com/en/download>
- Or contact your sales representative at Hesai
- Or contact Hesai's technical support team: [service@hesaitech.com](mailto:service@hesaitech.com)

## ■ Technical Support

If your question is not addressed in this user manual, please contact us at:

[service@hesaitech.com](mailto:service@hesaitech.com)

[www.hesaitech.com/en/support](http://www.hesaitech.com/en/support)

<https://github.com/HesaiTechnology>

(Please leave your questions under the corresponding GitHub projects.)

## ■ Legends


 Warnings: instructions that must be followed to ensure safe and proper use of the product.

 Notes: additional information that may be helpful.

# Safety Notice

## ■ Special Warnings

### Laser Safety



### Hot Surface



**Hot parts!**  
Burned fingers when handling the parts.  
Wait one-half hour after switching off before handling parts.

## **Abnormalities**

In any of the circumstances listed below, stop using the product immediately:

- You suspect that the product malfunctions or is damaged. For example, the product produces significant noise or is visibly vibrating.
- You or other people in the nearby environment feel discomfort.
- Any device or equipment in the nearby environment malfunctions.

Meanwhile, contact Hesai Technology or an authorized Hesai Technology service provider for more information on product disposal.

## **Prohibition of Disassembly**

Unless expressly agreed to in writing by Hesai Technology, do NOT disassemble the product.

## **■ Operating Environment**

### **Radio Frequency Interference**

Before using the product, make sure to read all the signs and notices on the product enclosure (including the bottom plate). Although the product is designed, tested, and manufactured to comply with the regulations on RF radiation (such as FCC, CE-EMC, or KCC), the radiation from the product may still influence electronic devices.

### **Vibration**

- If significant mechanical shocks and vibration may exist in the product's operating environment, please contact Hesai's technical support team to obtain the shock and vibration limits of this product model. Exposure to over-the-limit shocks or vibration may damage the product.
- Make sure to package the product in shock-proof materials to avoid damage during transport.

### **Explosive Atmosphere and Other Air Conditions**

- Do NOT use the product in any area where potentially explosive atmospheres are present, such as high concentrations of flammable chemicals, vapors, or particulates (including particles, dust, and metal powder) in the air.
- Do NOT expose the product to high concentrations of industrial chemicals, including liquefied gases that are easily vaporized (such as helium). Such exposure can damage or weaken the product's function.

### **Ingress Protection**

Please check the product's user manual for its IP rating (refer to the *Specifications* section). Make sure to avoid any ingress beyond that rating.

### **Operating Temperature**

Please check the product's user manual for its operating temperature (refer to the *Specifications* section). Make sure not to exceed the operating temperature range.

### **Recommended Storage Conditions**

Store the product in a dry, well-ventilated place. The recommended ambient temperature is  $23 \pm 5^{\circ}\text{C}$ , and the humidity between 30% and 70%.

### **Light Interference**

Certain precision optical instruments may be interfered by the laser light emitted from the product. Please check all the instructions of these instruments and take preventive measures if necessary. For example, when the product is temporarily not used for measurement, the protective cover (supplied with the product) can be used to block laser light emission.

## ■ Personnel

### Recommended Operator Qualifications

The product should be operated by professionals with engineering backgrounds or experience in operating optical, electrical, and mechanical instruments. Please follow the instructions in this manual when operating the product and contact Hesai technical support if needed.

### Medical Device Interference

- Some components in the product can emit electromagnetic fields. If the product operators or other people in the nearby environment wear medical devices (such as cochlear implants, heart pacemakers, and defibrillators), make sure to consult the physicians and medical device manufacturers for medical advice, such as determining whether it is safe to work near the product.
- If you suspect that the product is interfering with your medical device, stop using the product immediately.

## ■ Installation and Operation

### Power Supply

- You are recommended to use only the cables and power adapters provided by Hesai Technology.
- If you are to design, configure, or select the power supply system (including cables) for the product, make sure to comply with the electrical specifications in the product's user manual (refer to the *Specifications* section and the *Power Supply Requirements* section); for technical support, please contact Hesai Technology. Do NOT use off-spec or damaged cables or adapters.

### Electrical Interface

- Before powering on the product, make sure the electrical interfaces are dry and clean. Do NOT power on the product in a humid environment.
- Please check the *Interfaces* section in the product's user manual and strictly follow the instructions on plugging/unplugging the connector. If abnormalities already exist (such as bent pins, broken cables, and loose screws), stop using the product and contact Hesai technical support.
- To prevent breakdown, turn off the power source before connection and disconnection.

## Eye Safety

The product is a Class 1 laser product. It satisfies the requirements of:

- IEC 60825-1:2014, EN 60825-1:2014+A11:2021
- 21 CFR 1040.10 and 1040.11 except for deviations (IEC 60825-1 Ed.3) pursuant to Laser Notice No.56, dated May 8, 2019.

Please follow the standard laser safety guidelines accordingly.

For maximum self-protection, it is strongly warned NOT to look into the transmitting laser through a magnifying product (microscope, eye loupe, magnifying glass, etc.).

 This product does not have a power switch. It starts operating once connected to power. During operation, the entire cover lens can be regarded as the product's laser emitting window; looking at the cover lens can be regarded as looking into transmitting laser.

## Product Enclosure

- The product contains metal, glass, plastic, as well as sensitive electronic components. In case the product has been dropped and burnt, stop using it immediately and contact Hesai technical support.
- Do NOT squeeze or pierce the product. If the product enclosure is broken, stop using it immediately and contact Hesai technical support.
- The product contains high-speed rotating parts. To avoid potential injuries, do NOT operate the product if the enclosure is loose.
- Before operating the product, make sure it is properly and securely mounted. The mounting should prevent the product from leaving its mounting position in case of external forces (such as collisions, high winds, and stone impacts).
- If the product enclosure consists of fins or grooves, please wear gloves when handling the product. Applying too much pressure with your bare hands may cause cuts, bruises or other injuries.

## Product Enclosure: Cover Lens

- To keep the product's cover lens from fingerprints and other stains, do NOT touch the cover lens with bare hands. If the cover lens is already stained, please refer to the cleaning method in the *Sensor Maintenance* section of the user manual.
- To prevent scratches, do NOT touch the product's cover lens with hard or sharp objects. If scratches already exist, stop using the product and contact Hesai technical support. Severe scratches may affect the quality of the product's point cloud data.

## **Hot Surface**

During operation or a time period after operation, the product's enclosure can be hot.

- To prevent discomfort or even burns, do NOT touch the product's enclosure with your skin.
- To prevent fires, do NOT touch the product's enclosure with flammable materials.

## **Peripherals**

The product may be used along with accessories and devices, such as suction cup mounts, extension cables, power supplies, network devices, GPS/PTP devices, and cleaning equipment. Please refer to all relevant specifications in the product's user manual, or contact Hesai technical support. Using off-spec or unsuitable devices may result in product damage or even personal injuries.

## **Firmware and Software Upgrading**

Make sure to use only the upgrade files provided by Hesai Technology. Make sure to observe all the instructions provided for that upgrade file.

## **Custom Firmware and Software**

- Before using a custom version of firmware and software, please thoroughly understand the differences in functions and in performance between this custom version and the standard version.
- Make sure to strictly follow all the instructions and safety precautions provided for that custom version. If the product does not function as anticipated, stop using the product immediately and contact Hesai technical support.

## **Point Cloud Data Processing**

The point cloud data processing features (provided on certain product models) are configurable and are intended only to assist users in extracting information from the point cloud data. Users are in full control whether to use any of these features. Moreover, users are responsible for analyzing the product's intended application scenarios and evaluating the risks of enabling one or more of these features in combination. The point cloud data processing features include but are not limited to: Noise Filtering, Interstitial Points Filtering, Retro Multi-Reflection Filtering, and Nonlinear Reflectivity Mapping.

## ■ Repair and Maintenance

For product repair or maintenance issues, please contact Hesai Technology or an authorized Hesai Technology service provider. Contact information can be found in the product's user manual (refer to the *About this Manual* section).

### Repair

Unless expressly agreed to in writing by Hesai Technology, do NOT by yourself or entrust any third party to disassemble, repair, modify, or retrofit the product. Such a breach:

- can result in product damage (including but not limited to water resistance failure), property loss, and/or personal injuries;
- shall constitute a breach of warranty.

# 1 Introduction

This manual describes the specifications, installation, and data format of QT128C2X.

## 1.1 Operating Principle

Distance Measurement: Time of Flight (ToF)

- 1) A laser diode emits a beam of ultrashort laser pulses onto the target object.
- 2) The laser pulses are reflected after hitting the target object. The returning beam is detected by an optical sensor.
- 3) Distance to the object can be accurately measured by calculating the time between laser emission and receipt.

$d = \frac{ct}{2}$	d: distance c: speed of light t: travel time of the laser beam
--------------------	--

Figure 1.1 Distance Measurement Using Time of Flight

## 1.2 Lidar Structure

Laser emitters and receivers are attached to a motor that rotates horizontally.




Figure 1.2 Partial Cross-Sectional Diagram




Figure 1.3 Coordinate System (Isometric View)




Figure 1.4 Default Rotation Direction (Top View)

The lidar's coordinate system is illustrated in Figure 1.3. Z-axis is the axis of rotation.

By default, the lidar rotates clockwise in the top view. To select counterclockwise rotation, see Section 4.2 (Web Control - Settings).

The origin's exact position is shown in Figure 1.6, as a red dot. All measurements are relative to the origin.

Lidar azimuthal position is defined in Figure 1.4. Y-axis corresponds to 0°.

Each laser channel has an intrinsic azimuth offset. The horizontal center of the emitter-receiver array defines the lidar's azimuthal position.

For example, when the horizontal center passes the 90° position:

- the lidar is at the 90° position;
- the Azimuth field in the corresponding data block in the Point Cloud Data Packet will be 90°.

### 1.3 Channel Distribution

The vertical resolution is unevenly distributed across all channels, as illustrated in Figure 1.5 and detailed in Appendix I (Channel Distribution).




Figure 1.5 Channel Vertical Distribution




Figure 1.6 Laser Firing Position (Unit: mm)

Each channel has an intrinsic angle offset, both horizontally and vertically. The offsetted angles are recorded in this lidar unit's **angle correction file**. In case you need to obtain the file again:

- send PTC command 0x05, as described in Hesai TCP API Protocol (Chapter 5);
- or export the file using PandarView, see the PandarView user manual;
- or contact a sales representative or technical support engineer from Hesai.

The angle correction file lists the elevation and azimuth of each channel's outgoing beam, relative to the center of the exit pupil (shown as a yellow dot in Figure 1.6).

EEFF	1	1
LaserID	Elevation	Azimuth
1	-52.62676282	10.10830596
2	-51.0280939	9.719503673
3	-49.51495392	9.384265827
...	...	...
128	52.62676282	-10.10830596

Figure 1.7 Illustration of the Angle Correction File

## 1.4 Specifications

SENSOR		MECHANICAL/ELECTRICAL/OPERATIONAL		
Scanning Method	Mechanical Rotation	Wavelength	940 nm	
Channel	128	Laser Class	Class 1 Eye Safe	
Instrument Range	0.05 to 50 m	Ingress Protection	IP6K7 & IP6K9K	
Range Capability ①	Channels 9 to 120:	20 m	Dimensions	
	Channels 1 to 8, 121 to 128:	15 m		
(both at 10% reflectivity)		Rated Voltage Range	DC 12 to 48 V	
Range Accuracy ②	±3 cm (typical)	Power Consumption ③	12 W	
Range Precision ②	2 cm (typical)	Operating Temperature	-40°C to 85°C	
FOV (Horizontal)	360°	Storage Temperature	-40°C to 95°C	
Resolution (Horizontal)	Channels 65 to 128:	0.4° (10 Hz)	Weight	
		0.8° (20 Hz)		
	Channels 1 to 64:	0.8° (10 Hz)		
		1.6° (20 Hz)		
FOV (Vertical)	105.2° (-52.6° to +52.6°)	DATA I/O		
Resolution (Vertical)	Channels 78 to 115	0.4° to 0.5°	Data Transmission	Ethernet (Automotive, 1000BASE-T1)
	Other channels	0.8° to 1.6°		Slave Mode
Frame Rate	10 Hz, 20 Hz	Measurements		Distance, Azimuth, Reflectivity
Return Modes	Single Return	Valid Data Points	Single Return:	864,000 points/sec
	(First, Second, Last, Strongest)		Dual Return:	1,728,000 points/sec
	Dual Return (5 modes)	Point Cloud Data Rate	Single Return:	42.08 Mbps
			Dual Return:	84.17 Mbps
		Clock Source		PTP
		PTP Clock Accuracy		≤1 μs (typical)
		PTP Clock Drift ④		≤1 μs/s

 Specifications are subject to change. Please refer to the latest version. (Continued on the next page)

(Continued)

① Range Capability

- Test conditions: normal incidence, 0 to 100 klux ambient illuminance, PoD (probability of detection) > 90%, FAR (false alarm rate) < 10E-5.
- See Appendix I (Channel Distribution) for the test data of each channel.

② Range Accuracy and Range Precision

- May vary with range, temperature, and target reflectivity.
- Range accuracy: difference between the average of multiple measurements and the true value, measured under the same conditions.
- Range precision: standard deviation of multiple measurements, measured under the same conditions.

③ Power Consumption

- Not including accessories such as the connection box.
- Rated input voltage: 12 to 48 V
- Allowable input voltage: 9 to 55 V
- Refer to Appendix III (Power Supply Requirements)

④ PTP Clock Drift

- Defined as the drift at a constant temperature after the lidar (slave clock) loses connection to the PTP master.

## 2 Setup

### 2.1 Mechanical Installation




Figure 2.1 Left View (Unit: mm)




Figure 2.2 Mounting Base (Unit: mm)

## 2.1.1 Recommended Installation




Figure 2.3 Recommended Installation

## 2.1.2 Notes on Screw Installation

### ■ Screw Type

SEMS screws (with pre-attached flat washers and lock washers) are recommended. Property class should be at least 4.8.

### ■ Threadlocker

Before fastening a screw, apply 1 or 2 dots of threadlocker in the thread fit area. LOCTITE® 263 Threadlocker is recommended. To ensure curing in place, wait for at least 12 hours before operating the lidar.

### ■ Screw Torque

The base material of the threaded holes is aluminum alloy instead of steel. Refer to the following table for the appropriate screw torque.

Thread Size	Recommended Screw Torque
M3	0.5 to 0.6 Nm
M4	1 to 1.5 Nm
M5	2 to 2.5 Nm
M6	3.5 to 4 Nm

### ■ Thread service life

25 times.

Each screwing counts as one time, so as each unscrewing.

## 2.2 Interfaces

A 8-pin Rosenberger male socket (with pins inside) is used, which includes power wires and a 1000BASE-T1 twisted-pair.

Rosenberger part number: MPS113-40MT5-Z




Figure 2.4 Connector Dimensions (Unit: mm)




Figure 2.5 Connector Pinout (8-pin)

## 2.2.1 Pin Description

Pin #	Signal	Voltage
1	VIN	12 to 48 V
2	Reserved	0 to 3.3 V
3	Reserved	0 to 3.3 V
4	NC	-

Pin #	Signal	Voltage
5	NC	-
6	GND	0 V
1-1	Ethernet_TRX+	-1 to 1 V
1-2	Ethernet_TRX-	-1 to 1 V



Please plug and unplug the connector with care. Do not pull, twist, or squeeze it with excessive force.

## 2.2.2 Cables (Ethernet)

OD (outside diameter) =  $4.0 \pm 0.1$  mm

Minimum bend radius:

Single	3 * OD
Multiple ( $\leq 10x$ )	$\geq 40$ mm
Multiple ( $> 10x$ )	10 * OD

### 2.2.3 Connector Use

Connection	Disconnection
<ul style="list-style-type: none"><li>• Turn off the power source.</li><li>• Push the plug straight into the socket until a click is heard.</li><li>• Push the red CPA to the bottommost position until a click is heard.</li></ul>	<ul style="list-style-type: none"><li>• Turn off the power source.</li><li>• Pull the red CPA with your fingernail until a click is heard.</li><li>• Firmly press down the water blue latch while pulling the plug from the socket.</li></ul>

#### Warnings

- DO NOT attempt to force open a connection by pulling on the cables or by twisting the connectors in any way. Doing so can loosen the connectors' shells, or even damage the contacts.
- In case a connector's shell is accidentally pulled off, stop using the connector and contact Hesai technical support.
- DO NOT attempt to assemble the connector's shell and cable collet; DO NOT connect a connector without its shell. Doing so may damage the lidar's circuits.
- Before connection, check the pins on the socket and the holes on the plug. In case of bent pins or damaged holes, stop using the connector and contact Hesai technical support.

 Connector mating cycles: minimum 10




Figure 2.4 Rosenberger Connection/Disconnection

## 2.3 Connection Box (Optional)

Users may connect the lidar directly or using a connection box.

The connection box converts automotive 1000BASE-T1 to 1000BASE-T typical Ethernet, as well as providing a power port.

Rosenberger part number: MPK110-1CAZ5-Z (female plug, on the connection box)




Figure 2.5 Connection Box - Connection (Unit: mm)

The wire gauges are listed below:

No.	Signal	Voltage	Wire Gauge	Wire Color
1	VIN	12 to 48 V	0.75 mm <sup>2</sup>	Red
2	Reserved	0 to 3.3 V	0.5 mm <sup>2</sup>	Brown/Red
3	Reserved	0 to 3.3 V	0.5 mm <sup>2</sup>	Yellow
4	NC	-	0.5 mm <sup>2</sup>	Orange

No.	Signal	Voltage	Wire Gauge	Wire Color
5	NC	-	0.5 mm <sup>2</sup>	Blue
6	GND	0 V	0.75 mm <sup>2</sup>	Black
1-1	Ethernet_TRX+	-1 to 1 V	0.14 mm <sup>2</sup>	White
1-2	Ethernet_TRX-	-1 to 1 V	0.14 mm <sup>2</sup>	Green

## ■ Connection Box Interfaces




Figure 2.6 Connection Box (Front)

Port #	Port Name	Description
a	Standard Ethernet Port	RJ45, 1000BASE-TX Ethernet
b	Power Port	Connects to a DC power adapter Connector part number: PJ-057AH
c	Reserved Port	Do not connect this port to external signals




Figure 2.7 Connection Box (Back)

Port #	Port Name	Description
d	Reserved Port	Do not connect this port to external signals
e	Connection to lidar	See Section 2.2.1 (Pin Description). Connector (socket): Rosenberger, 99S2HC-40MT5-Z Recommended wire connector (plug): Rosenberger, 99K1HC-1CAZ5-Z

■ Connection




Figure 2.8 Connection with PTP (Software Simulation)




Figure 2.9 Connection with PTP (Hardware Device)

## 2.4 Get Ready to Use

Before operating the lidar, strip away the protective cover outside the cover lens.

The lidar does not have a power switch. It starts operating once connected to power and the Ethernet.

To receive data on your PC, set the PC's IP address to 192.168.1.100 and subnet mask to 255.255.255.0

For Ubuntu:	For Windows:
Input this ifconfig command in the terminal: ~\$ sudo ifconfig enp0s20f0u2 192.168.1.100 (replace enp0s20f0u2 with the local Ethernet port name)	Open the Network Sharing Center, click on "Ethernet" In the "Ethernet Status" box, click on "Properties" Double-click on "Internet Protocol Version 4 (TCP/IPv4)" Configure the IP address to 192.168.1.100 and subnet mask to 255.255.255.0

To record and display point cloud data, see PandarView User Manual.

To set parameters, check device info, or upgrade firmware/software, see Chapter 4 (Web Control)

# 3 Data Structure

The lidar outputs Point Cloud Data Packets.

Unless otherwise specified, all the multi-byte fields are unsigned values in little endian format.




Figure 3.1 Data Structure

## 3.1 Point Cloud Data Packet

### 3.1.1 Ethernet Header

Each lidar has a unique MAC address. The source IP is 192.168.1.201 by default, and the destination IP is 255.255.255.255 (broadcast).

Point Cloud Ethernet Header: 42 bytes		
Field	Bytes	Description
Ethernet II MAC	12	Destination: broadcast (0xFF: 0xFF: 0xFF: 0xFF: 0xFF: 0xFF) Source: (xx:xx:xx:xx:xx:xx)
Ethernet Data Packet Type	2	0x08, 0x00
Internet Protocol	20	Shown in the figure below
UDP Port Number	4	UDP source port (0x2710, representing 10000) Destination port (0x0940, representing 2368)
UDP Length	2	8 bytes more than the size of the Point Cloud UDP Data
UDP Checksum	2	-

```

v Internet Protocol Version 4, Src: 192.168.1.201, Dst: 255.255.255.255
  0100 .... = Version: 4
  .... 0101 = Header Length: 20 bytes (5)
  > Differentiated Services Field: 0x00 (DSCP: CS0, ECN: Not-ECT)
  Total Length: 1155
  Identification: 0x7af1 (31473)
  > Flags: 0x4000, Don't fragment
  ...0 0000 0000 0000 = Fragment offset: 0
  Time to live: 64
  Protocol: UDP (17)
  Header checksum: 0xf880 [validation disabled]
  [Header checksum status: Unverified]
  Source: 192.168.1.201
  Destination: 255.255.255.255
```

Figure 3.2 Point Cloud Ethernet Header - Internet Protocol

### 3.1.2 UDP Data

#### ■ Pre-Header: 6 bytes

Field	Bytes	Description
0xEE	1	SOP (start of packet)
0xFF	1	SOP (start of packet)
Protocol Version Major	1	Main class of the point cloud UDP packet structure Currently 0x03
Protocol Version Minor	1	Subclass of the point cloud UDP packet structure Currently 0x02
Reserved	2	-

■ Header: 6 bytes

Field	Bytes	Description
Laser Num	1	0x80 (128 channels)
Block Num	1	0x02 (2 blocks per packet)
First Block Return	1	Reserved
Dis Unit	1	0x04 (4 mm)
Return Num	1	Number of returns that each channel generates 0x01 - one return      0x02 - two returns
Flags	1	[7] and [5:4] are reserved The other bits show whether this data packet contains the following information [6] channel customization      1 - Selected channels      0 - All channels [3] digital signature              1 - YES      0 - NO [2] functional safety              1 - YES      0 - NO [1] IMU                                1 - YES      0 - NO [0] UDP sequence                  1 - YES      0 - NO

■ **Body: 1032 bytes (2 blocks)**

Field	Bytes	Description
Azimuth 1	2	For Block 1: current reference angle of the rotor azimuth angle in degrees = Azimuth / 100
Block 1	512	For Block 1: measurements made by each channel, starting form Channel 1 See table below
Azimuth 2	2	For Block 2
Block 2	512	For Block 2
CRC 1	4	CRC-32/MPEG-2 checksum of the Body 💡 For more on the CRC-32/MPEG-2 computation algorithm, refer to: <a href="https://www.mathworks.com/matlabcentral/fileexchange/72226-crc-32-mpeg-2-computation-algorithm">https://www.mathworks.com/matlabcentral/fileexchange/72226-crc-32-mpeg-2-computation-algorithm</a>

<b>Each Channel in the Block: 4 bytes</b>			
Each Block in the Body: 4 * 128 = 512 bytes			
Field	Bytes	Description	
Channel X	4	2-byte Distance	Distance Value = Distance * Dis Unit (See "Header" in this section)
		1-byte Reflectivity	Reflectivity Value = Reflectivity * 1% Range: 0 to 255
		1-byte Reserved	-

Four single-return modes and five dual-return modes are available, indicated by the Return Mode field in the Tail of Point Cloud Data Packets.

In a single-return mode, Blocks 1 and 2 use Firing Sequences 1 and 2, respectively.

 **Notes**

- Firing sequences are defined in Appendix II (Absolute Time of Point Cloud Data).
- If a channel does not fire in the current firing sequence, its corresponding four bytes are filled with 0.

In a dual-return mode:

- the measurements from each round of firing are stored in the two blocks of one packet (see table below);
- azimuth changes every packet;
- firing sequence changes every packet, indicated by the Mode Flag field in the Tail.

Return Mode field	Block 1	Block 2	Note
0x39	Last return	Strongest return	If the last return is also the strongest, then the even-number block stores the second strongest return.
0x3B	First return	Last return	If there is only one return, then the two blocks store the same data.
0x3C	First return	Strongest return	If the first return is also the strongest, then the even-number block stores the second strongest return.
0x3E	Strongest	Second Strongest	If there is only one return, then the two blocks store the same data.
0x3A	First	Second	If there is only one return, then the two blocks store the same data.

■ **Functional Safety: 17 bytes**

Field	Bytes	Description
FS Version	1	Version number of the functional safety module (currently 0x01)
Lidar State	1	[7:5] is the lidar's current state: d-0 (b-000) Init d-1 (b-001) Normal d-2 (b-010) Report Fault d-3 (b-011) Pre-Performance Degradation d-4 (b-100) Performance Degradation d-5 (b-101) Pre-Shutdown d-6 (b-110) Shutdown d-7 (b-111) Standby
Fault Code Type		[4:3] is the type of the fault code in this data packet b-01: current fault b-10: past fault
Rolling Counter		[2:0] indicates whether the fault reporting system gets stuck Starting from 0, the rolling counter increments by 1 every time the fault message is updated Normally, the fault message is updated every 5 ms
Total Fault Code Num	1	[7:4] counts the total number of fault codes in this queue
Fault Code ID		[3:0] is the sequence number of the fault code in this queue, starting from 1
Outgoing Fault Code	2	Fault code sent by this data packet
Reserved	8	-
CRC 2	4	CRC-32/MPEG-2 checksum of Functional Safety (from the Lidar State field to the Reserved field)

 The lidar states and fault codes are described in the Safety Manual. Please contact Hesai technical support for more information.

■ Tail: 34 bytes

Field	Bytes	Description
Reserved	5	-
Mode Flag	1	<p>[7:1] is reserved.</p> <p>[0] indicates the firing sequence used in Block 1.</p> <p>1 – Firing Sequence 1 (default)      0 – Firing Sequence 2</p> <p> Firing sequences are defined in Appendix II (Firing Time Offset of Each Channel).</p>
Reserved	6	-
Return Mode	1	<p>0x33 – First Return</p> <p>0x34 – Second Return</p> <p>0x37 – Strongest Return</p> <p>0x38 – Last Return</p> <p>0x39 – Dual Return (Last, Strongest)</p> <p>0x3B – Dual Return (First, Last)</p> <p>0x3C – Dual Return (First, Strongest)</p> <p>0x3E – Dual Return (Strongest, Second Strongest)</p> <p>0x3A – Dual Return (First, Second)</p>
Motor Speed	2	Unit: RPM

Field	Bytes	Description	
Date & Time	6	The absolute UTC time of this data packet, accurate to the second.	
		Each Byte	Range
		Year (current year minus 1900)	$\geq 70$
		Month	1 to 12
		Day	1 to 31
		Hour	0 to 23
		Minute	0 to 59
		Second	0 to 59
Timestamp	4	The " $\mu$ s time" part of the absolute time of this data packet (defined in Appendix II) Unit: $\mu$ s Range: 0 to 1000000 $\mu$ s (1 s)	
Factory Information	1	0x42	
UDP Sequence	4	Sequence number of this UDP packet 0 to 0xFF FF FF FF	
CRC 3	4	CRC-32 checksum of Functional Safety (from the Lidar State field to the Channel Health field)	

■ Cyber Security: 32 bytes

Field	Bytes	Description
Signature	32	<p>Point cloud signature</p> <p>Calculated using Point Cloud UDP Data (from Pre-Header to Tail, appended with UDP Sequence)</p> <p>Algorithm: HMAC-SHA256 (256 bits)</p> <p>Data is set to zero when this function is off.</p> <p> This field is added after specifying a Shared Secret Key and starting a session, see Section 4.9.3 (Web Control - Cybersecurity Configuration - Point Cloud Signature).</p>

### 3.1.3 Point Cloud Data Analysis

Take Channel 5 in Block 2 as an example:

#### ■ Analyze the vertical angle of a data point

The designed vertical angle of Channel 5 is  $-46.695^\circ$ , according to Appendix I (Channel Distribution)

#### Notes

- The accurate vertical angle is recorded in this LiDAR's unit's angle correction file, see Section 1.3 (Channel Distribution).
- $0^\circ$  is the horizontal direction; define upward as positive (see Figure 1.5).
- Channel # counts from 1, bottom to top.

#### ■ Analyze the horizontal angle of a data point

 Y-axis is the  $0^\circ$  position; define clockwise in the top view as positive (see Figure 1.4).

Horizontal angle = ① + ②

- ① Angular position of current block (see Appendix II for definition)
- ② Firing time angular offset of the current firing channel

$$\textcircled{1} = \textcircled{3} + \textcircled{4}$$

$\textcircled{3}$  Rotor reference angle during the current round of firing  
In the Azimuth field of Block 2.

$\textcircled{4}$  Horizontal angle offset of the current firing channel

The designed offset for Channel 5 is  $8.833^\circ$ , according to Appendix I (Channel Distribution Table).

 The accurate horizontal angle offset is recorded in this lidar's unit's angle correction file, see Section 1.3 (Channel Distribution).

$$\textcircled{2} = \textcircled{5} * \textcircled{6}$$

$\textcircled{5}$  Firing time offset of the current firing channel

Look up the table in Appendix II (Absolute Time of Point Cloud Data).

$\textcircled{6}$  Spin rate of the motor


See Section 4.1 (Web Control – Home).

### ■ Analyze the distance of a data point

Actual distance in real world millimeters = distance measurement \* Distance Unit

- Distance measurement: Distance field of Channel 5 in Block 2
- Dis Unit field in the Header: 4 mm

- Draw the data point in a polar or rectangular coordinate system



- Obtain the real-time point cloud data by analyzing and drawing every data point in each frame

## 4 Web Control

Web control is used for setting parameters, checking device info, and upgrading.

To access web control

- 1) Connect the lidar to your PC using an Ethernet cable
- 2) Set the IP address according to Section 2.4 (Get Ready to Use)
- 3) Enter this URL into your web browser: 192.168.1.201

 Google Chrome and Mozilla Firefox are recommended.

## 4.1 Home

<b>Status</b>	
Spin Rate	600 rpm
PTP	Free Run

<b>Device Info</b>	
Model	QT128C2X
P/N	QT128C2X-C02
S/N	QTXXXXXXXXXXXXXXXX
MAC Address	XX:XX:XX:XX:XX:XX
Software Version	3.1.17
Sensor Firmware Version	3.1.13
Controller Firmware Version	3.1.12

Parameter	Description	
Spin Rate	Spin Rate of the motor (rpm) = frame rate (Hz) * 60	
PTP	PTP status	
	Free Run	No PTP master is selected.
	Tracking	Attempting to sync with the selected PTP Master, but the absolute offset exceeds the user-specified limit in Section 4.2 (Settings).
	Locked	Absolute offset is within the user-specified limit.
	Frozen (Holdover)	Attempting to recover the connection to the PTP master.

## 4.2 Settings

[Reset All Settings](#)

---

**Control IP**

---

IPv4 Address	192.168.1.201
IPv4 Mask	255.255.255.0
IPv4 Gateway	192.168.1.1

**Settings**

---

Destination IP	255.255.255.255
Lidar Destination Port	2368
Spin Rate	600 rpm
Return Mode	First and Last Return
Sync Angle	<input type="checkbox"/> 0
Trigger Method	Time Based

(Continued on the next page)

(Continued)

Clock Source	<b>PTP</b>
Profile	1588v2
PTP Network Transport	UDP / IP
PTP Domain Number [0-127]	0
PTP logAnnounceInterval	1
PTP logSyncInterval	1
PTP logMinDelayReqInterval	0
Time Offset for Lidar Lock (1-100 $\mu$ s)	1
Retro Multi-Reflection Filtering	OFF
Rotation Direction	Clockwise
Standby Mode	In Operation / Standby

[Save](#)

Button	Description
Reset All Settings	Reset all the configurable parameters to factory defaults, including: <ul style="list-style-type: none"><li>• Section 4.2 (Settings)</li><li>• Section 4.3 (Azimuth FOV)</li></ul>
Save	Save and execute all the settings on this page. <ul style="list-style-type: none"><li>• Exception: Standby Mode takes effect immediately.</li></ul>

### 4.2.1 Network Settings

Parameter	Options	Description								
Destination IP	Any address except for 0.0.0.0, 127.0.0.1, and the lidar's IP.  Default: 255.255.255.255	<table border="1"> <thead> <tr> <th>Mode</th> <th>Destination IP</th> </tr> </thead> <tbody> <tr> <td>Broadcast (default)</td> <td>255.255.255.255</td> </tr> <tr> <td>Multicast</td> <td>User-defined</td> </tr> <tr> <td>Unicast</td> <td>Same as the PC's IP address</td> </tr> </tbody> </table>	Mode	Destination IP	Broadcast (default)	255.255.255.255	Multicast	User-defined	Unicast	Same as the PC's IP address
Mode	Destination IP									
Broadcast (default)	255.255.255.255									
Multicast	User-defined									
Unicast	Same as the PC's IP address									

### 4.2.2 Function Settings

Parameter	Options	Description
Spin Rate	600 RPM (default) 1200 RPM	The setting spin rate is also shown on web control, see Section 4.1 (Web Control – Home).
Return Mode	Single Return <ul style="list-style-type: none"> <li>• First / Strongest / Last / Second Return</li> </ul> Dual Return <ul style="list-style-type: none"> <li>• First and Last Return (default)</li> <li>• Last and Strongest Return</li> <li>• First and Strongest Return</li> <li>• Strongest and 2<sup>nd</sup> Strongest Return</li> <li>• First and Second Return</li> </ul>	Also shown in Point Cloud Data Packets, see the Return Mode field in Section 3.1.2 (Point Cloud UDP Data).

Parameter	Options	Description				
Sync Angle	0° to 360°	<p>Phase lock angle</p> <ul style="list-style-type: none"> <li>To activate this function, check the checkbox and input an azimuth.</li> <li>At every full second, the lidar will rotate to that azimuthal position.</li> </ul> <p>Lidar azimuthal position is defined in Section 1.2 (Lidar Structure).</p> <p>Definition of full second</p> <ul style="list-style-type: none"> <li>When PTP is tracking or locked: retrieved from the PTP master clock</li> <li>Otherwise: the rising edge of the lidar's internal 1 Hz signal</li> <li>Detailed in Appendix II (Absolute Time of Point Cloud Data)</li> </ul> <p>To phase-lock multiple lidars</p> <ul style="list-style-type: none"> <li>Connect the lidars to the same clock source and set the same sync angle, and these lidars will rotate to that same azimuthal position at every full second.</li> </ul>				
Trigger Method	Angle-Based Time-Based (default)	<p>The way laser firings are triggered.</p> <table border="1" data-bbox="974 965 1921 1066"> <tr> <td>Time-based</td> <td>lasers fire every 111.11 us.</td> </tr> <tr> <td>Angle-based</td> <td>lasers fire every 0.4° at 10 Hz, or every 0.8° at 20 Hz</td> </tr> </table>	Time-based	lasers fire every 111.11 us.	Angle-based	lasers fire every 0.4° at 10 Hz, or every 0.8° at 20 Hz
Time-based	lasers fire every 111.11 us.					
Angle-based	lasers fire every 0.4° at 10 Hz, or every 0.8° at 20 Hz					
Retro Multi-Reflection Filtering	OFF (default) ON	To mitigate the false positives at twice the distance of a retroreflector.				
Rotation Direction	Clockwise (default) Counterclockwise	💡 After selecting Counterclockwise, refresh the webpage to check that the settings have taken effect. If the page after refreshing still shows Clockwise, refresh the page again and check.				

Parameter	Options	Description
Standby Mode	In Operation (default) Standby	In Standby mode, the motor stops running and lasers stop firing.

### 4.2.3 Time Settings

Clock Source	<b>PTP</b>
Profile	1588v2
PTP Network Transport	UDP/IP
PTP Domain Number	0
PTP logAnnounceInterval	1
PTP logSyncInterval	1
PTP logMinDelayReqInterval	0
Time Offset for Lidar Lock	1

Parameter	Options	Description				
Clock Source	PTP	Detailed in Appendix III (PTP Protocol)				
Profile	1588v2 (default) 802.1AS 802.1AS Automotive	IEEE timing and synchronization standard				
Time Offset for Lidar Lock	1 to 100 $\mu$ s (integer)	Specify the upper limit of the absolute offset between Slave and Master when the lidar is in PTP Locked status. See Section 4.1 (Home)				
PTP Network Transport	UDP/IP (default) L2	Network transport protocol <table border="1" data-bbox="898 1201 1603 1302"> <tr> <td>UDP/IP</td> <td>Available only for 1588v2 profile</td> </tr> <tr> <td>L2</td> <td>Available for all profiles</td> </tr> </table>	UDP/IP	Available only for 1588v2 profile	L2	Available for all profiles
UDP/IP	Available only for 1588v2 profile					
L2	Available for all profiles					

Parameter	Options	Description
Domain Number	0 to 127 (integer) Default: 0	Domain attribute of the local clock

When using the 1588v2 profile:

Parameter	Options	Description
PTP logAnnounceInterval	-2 to 3 Default: 1	Time interval between Announce messages Default: 1 log second (2 seconds)
PTP logSyncInterval	-7 to 3 Default: 1	Time interval between Sync messages Default: 1 log second (2 seconds)
PTP logMinDelayReqInterval	-7 to 3 Default: 0	Minimum permitted mean time between Delay_Req messages Default: 0 log second (1 second)

### 4.3 Azimuth FOV

Azimuth FOV Setting

For all channels ▼

Button	Description
Save	Save and execute all the settings on this page.

Parameter	Options	Description
Azimuth FOV Setting	For all channels (default)	Configuration mode of the azimuth FOV.
	Multi-section FOV	The lidar outputs valid data only within the specified azimuth FOV ranges.

 **Note**

- The angles in degrees are accurate to the first decimal place.
- If the Start Angle is larger than the End Angle, then the actual range is the union of [Start Angle, 360°] and [0°, End Angle].
  - For instance, when the angle range is set to be [270°, 90°], the actual azimuth FOV is [270°, 360°] ∪ [0°, 90°].

### 4.3.1 For all channels

Input a Start Angle and an End Angle to form a continuous angle range.  
This range applies to all channels.

Azimuth FOV Setting	<input type="text" value="For all channels"/>
Azimuth FOV for All Channels	Start: <input type="text" value="0.0"/>
	End: <input type="text" value="360.0"/>
<input type="button" value="Save"/>	

### 4.3.2 Multi-section FOV

Input multiple ( $\leq 2$ ) sets of Start Angles and End Angles to form multiple continuous angle ranges.

Azimuth FOV SettingMulti-section FOV ▾

Enable/Disable All

Status	Group Channel	Azimuth FOV 1		Azimuth FOV 2	
		Start Angle	End Angle	Start Angle	End Angle
<input type="radio"/>	1~16	0.0	0.0	0.0	0.0
<input type="radio"/>	17~32	0.0	0.0	0.0	0.0
<input type="radio"/>	33~48	0.0	0.0	0.0	0.0
<input type="radio"/>	49~64	0.0	0.0	0.0	0.0
<input type="radio"/>	65~80	0.0	0.0	0.0	0.0
<input type="radio"/>	81~96	0.0	0.0	0.0	0.0
<input type="radio"/>	97~112	0.0	0.0	0.0	0.0
<input type="radio"/>	113~128	0.0	0.0	0.0	0.0

## 4.4 Operation Statistics

These operating parameters are shown in real time:

Start-Up Counts	146
Internal Temperature	56.26°C
System Uptime	0 h 5 min
Total Operation Time	559 h 43 min
<hr/>	
<b>Internal Temperature</b>	<b>Operation Time</b>
<hr/>	
< -40 °C	0 h 1 min
-40 to -20 °C	0 h 46 min
...	...
100 to 120 °C	1 h 44 min
>120 °C	0 h 0 min

## 4.5 Upgrade

### Preparation

- Please contact Hesai technical support to receive encrypted and signed upgrade files.
- During the upgrade, it is recommended to place a protective cover (supplied with the lidar) or other opaque material over the lidar's cover lens.

### Upgrade

- Click the "Upload" button, select an upgrade file, and confirm your choice in the pop-up window.
- When the upgrade is complete, the lidar will automatically reboot, and the past versions will be logged in the Upgrade Log.

Button	Description
Restart	Software reboot Afterwards, the Start-Up Counts in the Operation Statistics page increments by 1.

Parameter	Current Value
Software Version	3.1.17
Firmware of Sensor Version	3.1.13
Firmware of Controller Version	3.1.12
Upgrade Log	-

 Above version numbers may be different from the actual. Please refer to the web page of the lidar used.

## 4.6 Log

The process logs in this page can be used for software troubleshooting.

Button	Description
Clear ALL	Clear all logs (not yet supported)
Download ALL	Download all logs

## 4.7 Security

Cyber Security (Master Switch) OFF

### Login Control

Authentication OFF

### Secure Connection

PTC Connection Non-TLS

HTTP Connection HTTP

### Point Cloud Signature

Share Secret Key ⓘ

Save

Cyber Security (Master Switch) ON

### Login Control

Authentication ON

Current Password Current Password [Forgot Password?](#)

New Password New Password

Confirm New Password Confirm New Password

### Secure Connection

PTC Connection TLS

HTTP Connection HTTPS

### Point Cloud Signature

Share Secret Key ⓘ

Save

As shown in the previous page, the available settings depend on the Cyber Security Master Switch:

	Cyber Security (Master Switch): OFF (Default)	Cyber Security (Master Switch): ON
Login Control	OFF http://192.168.1.201 redirects to the Home page.	ON https://192.168.1.201 redirects to the Login page, see Section 4.8 (Login).
Secure Connection	OFF Use PTC and HTTP (cleartext protocols).	ON Use PTCS and HTTPS (encrypted protocols).
Point Cloud Signature	Users can change the shared secret key.   <b>Notes</b> <ul style="list-style-type: none"> <li>Point cloud signature is deactivated by default. Its activation/deactivation is controlled by PTC commands, regardless of the Cyber Security Master Switch.</li> <li>See the PTC commands in Chapter 5 (Communication Protocol).</li> </ul>	

 Firmware and software upgrades are always encrypted and signed, regardless of the Cyber Security Master Switch.

## 4.7.1 Login Control

When the Cyber Security Master Switch is ON:

Parameter	Description
Authentication	Forced to be ON.
Current Password	When turning on/off the Cyber Security Master Switch or when changing the password, input here. <ul style="list-style-type: none"> <li>• Default password: <b>123456</b></li> <li>• To effectively implement login control, please change the default password and keep your new password securely.</li> <li>• Before returning a trial/loaner lidar or an RMA lidar to Hesai, please make sure to change the password back to default.</li> </ul>
New Password	Format <ul style="list-style-type: none"> <li>• 8 to 30 characters</li> <li>• Containing at least one digit and one letter (case sensitive)</li> <li>• Special characters are allowed</li> </ul>
Confirm New Password	-



In case the password is forgotten:

If <b>TLS</b> is selected for PTC Connection	Users can only <b>reset the password</b> : <ul style="list-style-type: none"> <li>• Click on "Forgot password?" and it redirects to the Reset Password page.</li> <li>• Contact Hesai technical support to obtain a verification code.</li> </ul>
If <b>mTLS</b> is selected for PTC Connection	Users are allowed to <b>change the password</b> (without providing the current password): <ul style="list-style-type: none"> <li>• Send this PTCS command <code>PTC_COMMAND_SET_WEB_LOGIN_PASSWD</code>. See Chapter 5 (Communication Protocol).</li> </ul>

## 4.7.2 Secure Connection

When the Cyber Security Master Switch is ON:

TLS:

Secure Connection	
PTC Connection	TLS
HTTP Connection	HTTPS

mTLS:

Secure Connection	
PTC Connection	mTLS
Client CA certificate name	<i>No file</i>
Certificate status	<i>Invalid</i>
Change Certificate	 Upload <span style="background-color: red; color: white; padding: 2px 5px;">Remove</span>
HTTP Connection	HTTPS


Parameter	Options	Description	
PTC Connection	TLS (default) mTLS	PTC connection mode	
		TLS (one-way auth)	Only the user authenticates the lidar.
		mTLS (two-way auth)	The user and the lidar authenticate each other, see Section 4.9.2 (mTLS). Recommended for enhanced security. After selecting mTLS, click the "Upload" button to upload a user certificate.
HTTP Connection	Forced to be HTTPS	HTTP connection mode	

### 4.7.3 Point Cloud Signature

Parameter	Options	Description
Shared Secret Key	8 to 32 digits or letters (case sensitive)	Used for negotiating a session key, see Section 4.9.3 (Cybersecurity Configuration - Point Cloud Signature).

## 4.8 Login

When the Cyber Security Master Switch on the Security page is ON, <https://192.168.1.201> redirects to the Login page.



**Hesai Technology**  
Empowering **Robots** | Perceiving **the World**  
*Mission Beyond Vision*

Username: admin  
Password: Password  
**Login**  
[Forgot password?](#)

Username	admin
Password	Default: <b>123456</b> To effectively implement login control, please change the default password (see Section 4.7 - Security) and keep your new password securely.

## 4.9 Cybersecurity Configuration

### ■ Cybersecurity Functions

Functions	Description
Login control	see Section 4.7 (Security)
Encrypted communication	PTCS and HTTPS, see Chapter 5 (Communication Protocol)
Point cloud signature	see Section 4.9.3 (Cybersecurity Configuration - Point Cloud Signature)
Encrypted and signed upgrade	see Section 4.5 (Upgrade)
Secure boot	-

 Firewall port exceptions: Port 9347 (PTC/PTCS), Port 80 (HTTP), Port 443 (HTTPS), and Ports 319 and 320 (PTP 1588v2)

### ■ Entity Certificate

An entity certificate is saved in each lidar unit, containing the unit's Serial Number.

- After logging into web control (<https://192.168.1.201>), click the padlock icon (  ) in the browser's address bar, and the entity certificate can be found under Page Info.
- If the URL in the address bar shows **http** instead of **https**, the entity certificate is not correctly loaded. Please contact Hesai technical support.

## 4.9.1 Import CA Certificates (Optional)

### ■ Types of CA Certificates

Three CA certificates are provided for each lidar shipment:

Certificate Type	Filename and Description
Root certificate	Hesai_Technology_Root_CA.crt.cer
Intermediate certificate	Hesai_Common_User_Intermediate_CA.crt.cer This filename may change.
Certificate chain	Hesai_Ca_Chain.crt Comprised of the above root and intermediate certificates.



In case you need to obtain the CA certificates again, contact a sales representative or technical support engineer from Hesai.

### ■ Import CA Certificates to Your Browser

Chrome and Firefox in Windows 10 are used as an example.



 If you choose not to import the CA certificate(s) into the browser, a warning will appear when accessing web control. Please select "trust this website" or "continue to this website".

1) Go to the Settings/Options/Preference page of your browser → Input "Certificate" in the search bar → Select "Manage/View Certificates"



2) In the pop-up dialog box

- If "Intermediate Certification Authorities" and "Trusted Root Certification Authorities" are two separate tabs (see left-hand screenshot), click "Import" to upload the intermediate certificate under the former tab, and upload the root certificate under the latter tab
- If only one tab is named "Authorities" (see right-hand screenshot), click "Import" to upload the intermediate and root certificates under this tab, or upload only the certificate chain file under this tab.



Follow the default settings in the Import Certificate wizard and click "Next" if applicable.

In case the following warnings appear, select "Trust this CA to identify websites".

Security Warning

 You are about to install a certificate from a certification authority (CA) claiming to represent:

Hesai Root CA

Windows cannot validate that the certificate is actually from "Hesai Root CA". You should confirm its origin by contacting "Hesai Root CA". The following number will assist you in this process:

Thumbprint (sha1): 748CF1DD 26A7211D E6AD7F71 EC970C17 F9C01921

Warning:  
If you install this root certificate, Windows will automatically trust any certificate issued by this CA. Installing a certificate with an unconfirmed thumbprint is a security risk. If you click "Yes" you acknowledge this risk.

Do you want to install this certificate?

Downloading Certificate

You have been asked to trust a new Certificate Authority (CA).

Do you want to trust "Hesai Professional LiDAR User Account" for the following purposes?



Trust this CA to identify websites.

Trust this CA to identify email users.

Before trusting this CA for any purpose, you should examine its certificate and its policy and procedures (if available).

Examine CA certificate

3) When the import is complete, the CA certificate appears in the dialog box. Double-click to see detailed information.



## 4.9.2 mTLS (Optional)

The lidar is in TLS (one-way auth) mode by default. mTLS (two-way auth) is recommended to enhance security:

- See Section 4.2 (Web Control - Settings) for uploading the user certificate.
- Before checking live point cloud data in PandarView, upload both the user certificate and the corresponding private key. See *PandarView User Manual* (Check Live Data).

Requirements for the user certificate (chain):

File Size	Within 10 KB
Certificate Version	X.509 v3
Depth of Chain	Unlimited
Validity Period	The lidar can only retrieve the current time by connecting to an external clock source (GPS/PTP). Without an external source, the lidar's system time does not reflect the current time. To make sure your user certificate is always valid (with or without an external clock source), <ul style="list-style-type: none"><li>• the start date of the validity period should be 2019-01-01 or an earlier date</li><li>• the expiry date should be later than the current date</li></ul>
Extensions	If certificate extensions are used: <ul style="list-style-type: none"><li>• Include a user_cert extension</li><li>• Include "TLS Web Client Authentication" in the "X509v3 Extended Key Usage" field</li></ul>

In mTLS mode,

- users can reset the password by sending the PTCS command *PTC\_COMMAND\_SET\_WEB\_LOGIN\_PASSWORD*, see Chapter 5 (Communication Protocol).
- when the lidar connects to a new PC, users need to login again and upload the user certificate for the new PC.
- in case the private key to the user certificate is forgotten, login and upload a new user certificate.

 Before shipping loaned lidars or lidars under RMA, make sure to remove the uploaded user certificate by clicking the "Clean" button on the Settings page of web control.

### 4.9.3 Point Cloud Signature (Optional)

A point cloud signature can be added to each Point Cloud Data Packet, see Section 3.1.2 (Point Cloud UDP Data).

- 1) When operating this lidar unit for the first time, specify a Shared Secret Key in Section 4.2 (Web Control - Settings).
- 2) Start a session using this PTC command *PTC\_COMMAND\_DP\_SIG\_SESSION\_START*, see Chapter 5 (Communication Protocol).

💡 In case of a reboot, start a session again.

The process of signature generation shown in the flowchart below:

- The client and the lidar negotiate and exchange random numbers, which are used for calculating a session key
- The session key is used for generating and verifying point cloud signature
- Point cloud signature is calculated using Point Cloud UDP Data (from Header to Tail, appended with UDP Sequence)




Figure 4.1 Generation of Point Cloud Signature

The session key is calculated as  $K_{\text{session}} = \text{HKDF}(\text{ikm}, \text{salt}, \text{info})$

ikm	user-defined Shared Session Key
salt	random numbers exchanged between client and lidar
info	application-specific contextual information; optional

# 5 Communication Protocol

To receive Hesai lidar's PTC (Pandar TCP Commands) and HTTP API Protocols, please contact Hesai technical support.

Lidar models that support cybersecurity can communicate using the encrypted PTCS (PTC over TLS) and HTTPS (HTTP over TLS) API.

- Data format is the same with the cleartext PTC/HTTP API.
- To use PTCS, make sure your TLS version is 1.3 or above, with OpenSSL 1.1.1 or above

The sample code for using PTC/PTCS, HTTP/HTTPS, and point cloud signature can be found at:

[https://github.com/HesaiTechnology/Cyber\\_Security](https://github.com/HesaiTechnology/Cyber_Security)

# 6 Sensor Maintenance

## ■ Cleaning

Stains on the product's cover lens, such as dirt, fingerprints, and oil, can negatively affect point cloud data quality. Please perform the following steps to remove the stains.

## ⚠ Warnings

- Turn OFF the power source before cleaning.
- To avoid damaging the optical coating, do NOT apply pressure when wiping the cover lens.

## 💡 Notes

- Only clean the stained area of the cover lens.
  - Check before using a lint-free wipe. If the wipe is stained, use another.
- 1) Thoroughly wash your hands or wear a pair of powder-free PVC gloves.
  - 2) To remove dust, blow dry air onto the cover lens, or use a piece of lint-free wipe to lightly brush across the dusty area.  
To remove persistent stains, move on to the next step.
  - 3) Spray the cover lens with warm, neutral solvent using a spray bottle.

Solvent type	99% isopropyl alcohol (IPA) or 99% ethanol (absolute alcohol) or distilled water  When using IPA or alcohol, please ensure adequate ventilation and keep away from fire.
Solvent temperature	20 to 25°C

(Continued on the next page)

(Continued)

- 4) When the stains have loosened, dip a piece of lint-free wipe into the solvent made in Step 3, and gently wipe the cover lens back and forth along its curved surface.
- 5) Should another cleaning agent be applied to remove certain stains, repeat Steps 3 and 4.
- 6) Spray the cover lens with clean water, and gently wipe off the remaining liquid with another piece of lint-free wipe.

# 7 Troubleshooting

In case the following procedures cannot solve the problem, please contact Hesai technical support.

Symptoms	Points to Check
Indicator light is off on the connection box	<p>Verify that:</p> <ul style="list-style-type: none"><li>• power adapter is properly connected and in good condition;</li><li>• connection box is intact;</li><li>• input voltage and current satisfy the requirements in Section 2.3 (Connection Box).</li></ul> <p>Power on again to check if the symptom persists.</p>
Motor is not running	<p>Verify that:</p> <ul style="list-style-type: none"><li>• power adapter is properly connected and in good condition;</li><li>• if a connection box is used, the connection box is intact;</li><li>• input voltage and current satisfy the requirements in Section 1.4 (Specifications) and 2.3 (Connection Box);</li><li>• web control can be accessed (see "cannot open web control" on the next page);</li><li>• the lidar is not in standby mode, see Section 4.2 (Web Control – Settings).</li></ul> <p>Power on again to check if the symptom persists.</p>

Symptoms	Points to Check
<p>Motor is running but no output data is received, neither on Wireshark nor on PandarView</p>	<p>Verify that:</p> <ul style="list-style-type: none"> <li>• Ethernet cable is properly connected (by unplugging and plugging again);</li> <li>• Lidar's Destination IP is correctly set on the Settings page of web control;</li> <li>• horizontal FOV is properly set on the Azimuth FOV page of web control;</li> <li>• firmware version of the sensor is correctly shown on the Upgrade page of web control;</li> <li>• Lidar is emitting laser light. This can be checked by using an infrared camera, an infrared sensor card, or a phone camera without infrared filter.</li> </ul> <p>If a connection box is used:</p> <ul style="list-style-type: none"> <li>• replace the current Ethernet cable with another cable of at least Cat 6; Cat 7 or higher is recommended.</li> </ul> <p>Power on again to check if the symptom persists.</p>
<p>Can receive data on Wireshark but not on PandarView</p>	<p>Verify that:</p> <ul style="list-style-type: none"> <li>• Lidar Destination Port is correctly set on the Settings page of web control;</li> <li>• PC's firewall is disabled, or that PandarView is added to the firewall exceptions;</li> <li>• PC's VLAN ID is the same as the lidar's; (<b>NOTE</b> This requirement applies only when the product model supports VLAN and that VLAN tagging is enabled.)</li> <li>• the latest version of PandarView is installed on the PC.</li> </ul> <p>Power on again to check if the symptom persists.</p>

Symptoms	Points to Check
Cannot open web control	<p>Verify that:</p> <ul style="list-style-type: none"> <li>• Ethernet cable is properly connected (by unplugging and plugging again);</li> <li>• Lidar's IP is in the same subnet with the PC's. Users may use WireShark to check the lidar's IP that broadcasts data packets;</li> <li>• PC's VLAN ID is the same as the lidar's. (<b>NOTE</b> This requirement applies only when the product model supports VLAN and that VLAN tagging is enabled.)</li> </ul> <p>Afterwards:</p> <ul style="list-style-type: none"> <li>• restart PC, or connect the lidar to another PC;</li> <li>• power on again to check if the symptom persists.</li> </ul>
Abnormal packet size (missing packets)	<p>Verify that:</p> <ul style="list-style-type: none"> <li>• horizontal FOV is properly set on the Azimuth FOV page of web control;</li> <li>• motor's spin rate is steady on the Home page of web control;</li> <li>• Lidar's internal temperature is between -40°C and 110°C on the Operation Statistics page of web control</li> <li>• Ethernet is not overloaded;</li> <li>• no switch is connected into the network. The data transmitted from other devices may cause network congestion and packet loss.</li> </ul> <p>Afterwards:</p> <ul style="list-style-type: none"> <li>• connect the PC only to the lidar and check for packet loss;</li> <li>• power on again to check if the symptom persists.</li> </ul>

Symptoms	Points to Check
<p>Abnormal point cloud (obviously misaligned points, flashing points, or incomplete FOV)</p>	<p>Verify that:</p> <ul style="list-style-type: none"> <li>• Lidar's cover lens is clean. If not, refer to Chapter 6 (Sensor Maintenance) for the cleaning method;</li> <li>• Lidar's calibration file is imported, see <i>PandarView User Manual</i> (Use);</li> <li>• horizontal FOV is properly set on the Azimuth FOV page of web control;</li> <li>• motor's spin rate is steady on the Home page of web control;</li> <li>• Lidar's internal temperature is between -40°C and 110°C on the Operation Statistics page of web control.</li> </ul> <p>Afterwards, check for packet loss:</p> <ul style="list-style-type: none"> <li>• If no packet is missing and yet the point cloud flashes, please update PandarView to the latest version (see the Download page of Hesai's official website or contact Hesai technical support) and restart the PC.</li> </ul> <p>If the point cloud is still abnormal:</p> <ul style="list-style-type: none"> <li>• try connecting the lidar to another PC;</li> <li>• power on again to check if the symptom persists.</li> </ul>

# Appendix I Channel Distribution

Notes to the table next page:

## ■ Angle Values

- The design values of Horizontal Angle (Azimuth) Offsets and Vertical Angles (Elevation) are listed.
- The accurate values are in this lidar unit's angle correction file, see Section 1.3 (Channel Distribution).

## ■ Channel No.

- All channels are listed in the ascending order of Channel No..
- In the vertical high-resolution region (19° to 36°), the vertical angles of Channels 78 to 96 alternate with those of Channels 97 to 115. Outside this region, Channel No. counts from bottom to top.

## ■ Division of Channels into Banks

All channels are divided into four banks.

Range of Channels	Name
Channels 97 to 128	Bank D
Channels 65 to 96	Bank C
Channels 33 to 64	Bank B
Channels 1 to 32	Bank A

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
1 (bottom)	Bank A	10.108°	-52.627°	15 m	0.8°
2	Bank A	9.720°	-51.028°	15 m	0.8°
3	Bank A	9.384°	-49.515°	15 m	0.8°
4	Bank A	9.091°	-48.074°	15 m	0.8°
5	Bank A	8.833°	-46.695°	15 m	0.8°
6	Bank A	8.603°	-45.369°	15 m	0.8°
7	Bank A	8.396°	-44.090°	15 m	0.8°
8	Bank A	8.209°	-42.852°	15 m	0.8°
9	Bank A	8.040°	-41.651°	20 m	0.8°
10	Bank A	7.885°	-40.482°	20 m	0.8°
11	Bank A	7.743°	-39.343°	20 m	0.8°
12	Bank A	7.612°	-38.231°	20 m	0.8°
13	Bank A	7.492°	-37.143°	20 m	0.8°
14	Bank A	7.380°	-36.076°	20 m	0.8°
15	Bank A	7.277°	-35.030°	20 m	0.8°
16	Bank A	7.180°	-34.002°	20 m	0.8°
17	Bank A	7.090°	-32.992°	20 m	0.8°
18	Bank A	7.006°	-31.996°	20 m	0.8°
19	Bank A	6.928°	-31.015°	20 m	0.8°
20	Bank A	6.854°	-30.048°	20 m	0.8°

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
21	Bank A	6.785°	-29.093°	20 m	0.8°
22	Bank A	6.721°	-28.149°	20 m	0.8°
23	Bank A	6.660°	-27.216°	20 m	0.8°
24	Bank A	6.602°	-26.292°	20 m	0.8°
25	Bank A	6.549°	-25.378°	20 m	0.8°
26	Bank A	6.498°	-24.473°	20 m	0.8°
27	Bank A	6.450°	-23.575°	20 m	0.8°
28	Bank A	6.405°	-22.685°	20 m	0.8°
29	Bank A	6.363°	-21.802°	20 m	0.8°
30	Bank A	6.323°	-20.926°	20 m	0.8°
31	Bank A	6.285°	-20.056°	20 m	0.8°
32	Bank A	6.250°	-19.191°	20 m	0.8°
33	Bank B	-6.217°	-18.331°	20 m	0.8°
34	Bank B	-6.186°	-17.477°	20 m	0.8°
35	Bank B	-6.157°	-16.627°	20 m	0.8°
36	Bank B	-6.129°	-15.781°	20 m	0.8°
37	Bank B	-6.104°	-14.940°	20 m	0.8°
38	Bank B	-6.080°	-14.102°	20 m	0.8°
39	Bank B	-6.057°	-13.268°	20 m	0.8°
40	Bank B	-6.037°	-12.436°	20 m	0.8°

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
41	Bank B	-6.018°	-11.608°	20 m	0.8°
42	Bank B	-6.000°	-10.783°	20 m	0.8°
43	Bank B	-5.984°	-9.960°	20 m	0.8°
44	Bank B	-5.969°	-9.139°	20 m	0.8°
45	Bank B	-5.955°	-8.320°	20 m	0.8°
46	Bank B	-5.943°	-7.503°	20 m	0.8°
47	Bank B	-5.927°	-6.688°	20 m	0.8°
48	Bank B	-5.923°	-5.874°	20 m	0.8°
49	Bank B	-5.915°	-5.061°	20 m	0.8°
50	Bank B	-5.908°	-4.250°	20 m	0.8°
51	Bank B	-5.902°	-3.439°	20 m	0.8°
52	Bank B	-5.897°	-2.630°	20 m	0.8°
53	Bank B	-5.894°	-1.820°	20 m	0.8°
54	Bank B	-5.892°	-1.012°	20 m	0.8°
55	Bank B	-5.891°	-0.203°	20 m	0.8°
56	Bank B	-5.891°	0.606°	20 m	0.8°
57	Bank B	-5.893°	1.414°	20 m	0.8°
58	Bank B	-5.896°	2.223°	20 m	0.8°
59	Bank B	-5.899°	3.033°	20 m	0.8°
60	Bank B	-5.905°	3.843°	20 m	0.8°

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
61	Bank B	-5.911°	4.654°	20 m	0.8°
62	Bank B	-5.919°	5.466°	20 m	0.8°
63	Bank B	-5.927°	6.279°	20 m	0.8°
64	Bank B	-5.938°	7.094°	20 m	0.8°
65	Bank C	5.949°	7.910°	20 m	0.4°
66	Bank C	5.962°	8.728°	20 m	0.4°
67	Bank C	5.976°	9.547°	20 m	0.4°
68	Bank C	5.992°	10.369°	20 m	0.4°
69	Bank C	6.008°	11.194°	20 m	0.4°
70	Bank C	6.027°	12.020°	20 m	0.4°
71	Bank C	6.047°	12.850°	20 m	0.4°
72	Bank C	6.068°	13.683°	20 m	0.4°
73	Bank C	6.091°	14.519°	20 m	0.4°
74	Bank C	6.116°	15.359°	20 m	0.4°
75	Bank C	6.143°	16.202°	20 m	0.4°
76	Bank C	6.171°	17.050°	20 m	0.4°
77	Bank C	6.201°	17.902°	20 m	0.4°
78	Bank C	6.233°	18.759°	20 m	0.4°
79	Bank C	6.267°	19.621°	20 m	0.4°
80	Bank C	6.304°	20.488°	20 m	0.4°

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
81	Bank C	6.343°	21.362°	20 m	0.4°
82	Bank C	6.384°	22.241°	20 m	0.4°
83	Bank C	6.427°	23.128°	20 m	0.4°
84	Bank C	6.474°	24.022°	20 m	0.4°
85	Bank C	6.523°	24.923°	20 m	0.4°
86	Bank C	6.575°	25.833°	20 m	0.4°
87	Bank C	6.631°	26.751°	20 m	0.4°
88	Bank C	6.690°	27.679°	20 m	0.4°
89	Bank C	6.752°	28.618°	20 m	0.4°
90	Bank C	6.819°	29.567°	20 m	0.4°
91	Bank C	6.890°	30.528°	20 m	0.4°
92	Bank C	6.966°	31.502°	20 m	0.4°
93	Bank C	7.047°	32.490°	20 m	0.4°
94	Bank C	7.134°	33.493°	20 m	0.4°
95	Bank C	7.227°	34.512°	20 m	0.4°
96	Bank C	7.327°	35.549°	20 m	0.4°
97	Bank D	-6.250°	19.191°	20 m	0.4°
98	Bank D	-6.285°	20.056°	20 m	0.4°
99	Bank D	-6.323°	20.926°	20 m	0.4°
100	Bank D	-6.363°	21.802°	20 m	0.4°

Channel Distribution  
(to be continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
101	Bank D	-6.405°	22.685°	20 m	0.4°
102	Bank D	-6.450°	23.575°	20 m	0.4°
103	Bank D	-6.498°	24.473°	20 m	0.4°
104	Bank D	-6.549°	25.378°	20 m	0.4°
105	Bank D	-6.602°	26.292°	20 m	0.4°
106	Bank D	-6.660°	27.216°	20 m	0.4°
107	Bank D	-6.721°	28.149°	20 m	0.4°
108	Bank D	-6.785°	29.093°	20 m	0.4°
109	Bank D	-6.854°	30.048°	20 m	0.4°
110	Bank D	-6.928°	31.015°	20 m	0.4°
111	Bank D	-7.006°	31.996°	20 m	0.4°
112	Bank D	-7.090°	32.992°	20 m	0.4°
113	Bank D	-7.180°	34.002°	20 m	0.4°
114	Bank D	-7.277°	35.030°	20 m	0.4°
115	Bank D	-7.380°	36.076°	20 m	0.4°
116	Bank D	-7.492°	37.143°	20 m	0.4°
117	Bank D	-7.612°	38.231°	20 m	0.4°
118	Bank D	-7.743°	39.343°	20 m	0.4°
119	Bank D	-7.885°	40.482°	20 m	0.4°
120	Bank D	-8.040°	41.651°	20 m	0.4°

Channel Distribution  
(continued)

Channel No.	Bank No.	Horizontal Angle (Azimuth) Offset	Vertical Angle (Elevation)	Range Capability @10% Reflectivity	Horizontal Resolution @10 Hz
121	Bank D	-8.209°	42.852°	15 m	0.4°
122	Bank D	-8.396°	44.090°	15 m	0.4°
123	Bank D	-8.603°	45.369°	15 m	0.4°
124	Bank D	-8.833°	46.695°	15 m	0.4°
125	Bank D	-9.091°	48.074°	15 m	0.4°
126	Bank D	-9.384°	49.515°	15 m	0.4°
127	Bank D	-9.720°	51.028°	15 m	0.4°
128 (top)	Bank D	-10.108°	52.627°	15 m	0.4°

# Appendix II Absolute Time of Point Cloud Data

## ■ Source of Absolute Time

The lidar retrieves the current absolute time by connecting to an external clock source (PTP).

- The lidar connects to a third-party PTP master to obtain the absolute time.
- Users may configure the PTP settings, see Section 4.2 (Web Control – Settings).
- Users may check the PTP signal status, see Section 4.1 (Web Control - Home).
- The lidar does not output GPS Data Packets.

The absolute time is updated as follows.

PTP Status	Date & Time (accurate to $\mu$ s)	Description
Free Run	Virtual	Starts counting from a virtual UTC time (such as 2000-01-01 00:00:00), using the lidar's internal 1 Hz signal.
Tracking or Locked	Synchronized	Extract the actual date and time from the PTP Master's messages.
Frozen	Drifting	Starts counting from the last synchronized time, using the lidar's internal 1 Hz signal. Will gradually drift from the actual GPS time.


## Notes

- PTP is a Plug & Play protocol; the lidar works as a PTP slave device and requires no additional setup.
- The timestamps and Date & Time fields in Point Cloud Data Packets strictly follow the PTP master device. Certain PTP master devices may have a specified offset from the lidar's time output. Please verify the configuration and calibration of your PTP master device.

## ■ Absolute Time of Point Cloud Data Packets

### Definition

- Every time the lidar passes a fixed time  $\Delta t$  or azimuth interval  $\Delta \alpha$  (see Section 4.2 Web Control – Trigger Method), it sends a command that triggers a round of firing.
- A round of firing can have either one or more returns (specified in Section 4.2 Web Control – Return Mode). The measurements of each return are stored in one block (see Section 3.1.2 UDP Data – Body).
- The absolute time of a Point Cloud Data Packet is the time when the lidar sends the command that triggers a round of firing that will be stored in the first block.



This absolute time is output to the **Date & Time** field and the **Timestamp** field in Point Cloud Data Packets.

### ■ Start Time of Each Block

Assuming that the absolute time of a Point Cloud Data Packet is  $t_0$ , the start time of each block (i.e., the time when the first firing starts) can be calculated.

#### Single Return Mode

Block	Start Time ( $\mu\text{s}$ )
Block 1	$t_0 + 9$
Block 2	$t_0 + 9 + 111.11$

#### Dual Return Mode

Block	Start Time ( $\mu\text{s}$ )
Block 1 & Block 2	$t_0 + 9$

## ■ Firing Sequences

All channels are divided into four banks, see Appendix I (Channel Distribution).

Two firing sequences are defined below and are executed alternately.

Firing Sequence 1	Firing Sequence 2
Banks CDB fire; Bank A rests	Banks CDA fire, Bank B rests

 The current firing sequence is indicated by the **Mode Flag** field in the Tail of Point Cloud Data Packets, see Section 3.1.2 (Point Cloud UDP Data).

## ■ Firing Time Offset of Each Channel

Assume that the start time of Block  $m$  is  $T(m)$ ,  $m \in \{1, 2\}$ , then the laser firing time of Channel  $n$  in Block  $m$  is

$$t(m, n) = T(m) + \Delta t(n), n \in \{1, 2, \dots, 128\}.$$

The firing time offsets  $\Delta t(n)$  are listed in the lidar unit's **firetime correction file**, shown in the table next page.

- LoopNum is the number of firing sequences.
- "Loop1" and "Loop2" are the firing channels of Firing Sequences 1 and 2, respectively. The firing channels are listed in the ascending order of  $\Delta t(n)$ .
- "Firetime1" and "Firetime2" are the firing time offsets  $\Delta t(n)$  (Unit:  $\mu\text{s}$ ), which are the same.
- The file contains 99 rows of effective data (3 header rows and 96 channel rows), appended by 32 all-zero rows (shown as ellipses in the table next page).

To obtain the firetime correction file:

- send PTC command 0xA9, as described in Hesai TCP API Protocol (Chapter 5);
- or export the file using PandarView, see the PandarView user manual.

Firetime Correction File  
(continued in the following pages)

EEFF	1	1	
Horizontal Resolution Mode	1	LoopNum	2
Loop1	Firetime1	Loop2	Firetime2
99	0.6	65	0.6
65	1.456	99	1.456
35	2.312	1	2.312
102	3.768	72	3.768
72	4.624	102	4.624
38	5.48	8	5.48
107	6.936	73	6.936
73	7.792	107	7.792
43	8.648	9	8.648
110	10.104	80	10.104
80	10.96	110	10.96
46	11.816	16	11.816
115	13.272	81	13.272
81	14.128	115	14.128
51	14.984	17	14.984
118	16.44	88	16.44
88	17.296	118	17.296
54	18.152	24	18.152
123	19.608	89	19.608
89	20.464	123	20.464
59	21.32	25	21.32

126	22.776	96	22.776
96	23.632	126	23.632
62	24.488	32	24.488
97	25.944	67	25.944
67	26.8	97	26.8
33	27.656	3	27.656
104	29.112	70	29.112
70	29.968	104	29.968
40	30.824	6	30.824
105	32.28	75	32.28
75	33.136	105	33.136
41	33.992	11	33.992
112	35.448	78	35.448
78	36.304	112	36.304
48	37.16	14	37.16
113	38.616	83	38.616
83	39.472	113	39.472
49	40.328	19	40.328
120	41.784	86	41.784
86	42.64	120	42.64
56	43.496	22	43.496
121	44.952	91	44.952
91	45.808	121	45.808
57	46.664	27	46.664
128	48.12	94	48.12
94	48.976	128	48.976

64	49.832	30	49.832
98	51.288	68	51.288
68	52.144	98	52.144
34	53	4	53
103	54.456	69	54.456
69	55.312	103	55.312
39	56.168	5	56.168
106	57.624	76	57.624
76	58.48	106	58.48
42	59.336	12	59.336
111	60.792	77	60.792
77	61.648	111	61.648
47	62.504	13	62.504
114	63.96	84	63.96
84	64.816	114	64.816
50	65.672	20	65.672
119	67.128	85	67.128
85	67.984	119	67.984
55	68.84	21	68.84
122	70.296	92	70.296
92	71.152	122	71.152
58	72.008	28	72.008
127	73.464	93	73.464
93	74.32	127	74.32
63	75.176	29	75.176
100	76.632	66	76.632

66	77.488	100	77.488
36	78.344	2	78.344
101	79.8	71	79.8
71	80.656	101	80.656
37	81.512	7	81.512
108	82.968	74	82.968
74	83.824	108	83.824
44	84.68	10	84.68
109	86.136	79	86.136
79	86.992	109	86.992
45	87.848	15	87.848
116	89.304	82	89.304
82	90.16	116	90.16
52	91.016	18	91.016
117	92.472	87	92.472
87	93.328	117	93.328
53	94.184	23	94.184
124	95.64	90	95.64
90	96.496	124	96.496
60	97.352	26	97.352
125	98.808	95	98.808
95	99.664	125	99.664
61	100.52	31	100.52
0	0	0	0
...	...	...	...
0	0	0	0

## Appendix III Power Supply Requirements

To ensure the input voltage at the lidar's connector is within 9 to 55 V DC, please check the specifications of the power supply and cables.

### ■ Power Supply

Should be able to provide at least 4 A, 30 W.

### ■ Cable Wire Gauge

The lidar uses 18 AWG power cables. We recommend using cables of 18 AWG or thicker wire gauges.

### ■ Minimum Source Voltage

Calculations can be made as follows:

- Cable length from the power source to the lidar connector is defined as  $L$  (unit: m).
- When using 18 AWG (24.7  $\Omega$ /km) cables, cable resistance is estimated as  $R_1 = 0.05L$  (unit:  $\Omega$ ).
- Resistance of the lidar connector described in Section 2.2 (Interfaces) is defined as  $R_2$ , excluding jumper cable assembly.  $R_2 \leq 20 \text{ m}\Omega$ .
- In all operating conditions, the lidar's peak power consumption  $P_{\text{peak}} \leq 30 \text{ W}$ .
- A conservative estimate of the minimum source voltage is

$$U_{\text{source,min}} = 9 + \frac{P_{\text{peak,max}}}{9} * (R_1 + R_{2,\text{max}}) \approx (9.1 + 0.2L) \text{ (unit: V)}.$$

(Continued on the next page)

(Continued)

Users may also estimate the minimum source voltage using the following lookup table.

Cable Total Length L	Minimum Source Voltage U
2 m	9.5 V
6 m	10.3 V
10 m	11.1 V
15 m	12.1 V

 When the lidar's input voltage approaches 55 V, make sure there is no additional overshoot in the external power system. Even a short period of overvoltage can cause irreversible damage to the lidar.

## Appendix IV Legal Notice

Copyright (C) 2017-2022 Hesai Technology Co., Ltd.

All rights reserved. Use or reproduction of this manual in parts or its entirety without the authorization of Hesai is prohibited.

Hesai Technology makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Further, Hesai Technology reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

HESAI and HESAI logo are registered trademarks of Hesai Technology. All other trademarks, service marks, and company names in this manual or on Hesai's official website are properties of their respective owners.

The software included in this product contains copyright that is registered under Hesai Technology. Any third party is not permitted, except as expressly permitted by licensor or expressly required by applicable law, to decompile, reverse engineer, disassemble, modify, rent, lease, loan, distribute, sublicense, create derivative works based on the whole or any part of the software.

Hesai Product Warranty Service Manual is on the Warranty Policy page of Hesai's official website: <https://www.hesaitech.com/en/legal/warranty>

## Hesai Technology Co., Ltd.

Phone: +86 400 805 1233

Website: [www.hesaitech.com](http://www.hesaitech.com)

Address: Building L2, Hongqiao World Centre, Shanghai, China

Business Email: [info@hesaitech.com](mailto:info@hesaitech.com)

Service Email: [service@hesaitech.com](mailto:service@hesaitech.com)



HESAI Wechat